


1 Follow the manufacturer's instructions.

Carefully follow the manufacturer's instructions for installing and maintaining your chimney or appliance. If you do not have instructions, call the manufacturer. For masonry chimneys, call the builder.




2 Inspect and clean your chimney regularly.

The Ontario Fire Code requires homeowners to maintain the safety of their chimneys and inspect them at least once a year. Your chimney could have a problem you cannot see. If in doubt, consult a WETT (Wood Energy Technical Training) certified chimney sweep.



3 Check stovepipes and connections.

Ensure screws are located at every joint. Also look for leaching (dark staining or white powder) at every joint. This could be a sign of chimney trouble - consult a WETT certified chimney sweep.




4 Check for creosote.

Creosote can form quickly and is a major cause of chimney fires. Check chimney and flue pipes often and clean when necessary- never let creosote or soot build up.

5 Check walls for excessive heat.

If the wall is very hot, it could be a sign of improper installation of the chimney or stove pipe. Check with a WETT certified chimney sweep.



6 Install a rain cap.

A rain cap should be installed on top of all metal and masonry chimneys. If you have a spark screen around the chimney cap, inspect it regularly for blockage.



9 Regularly check for signs of problems.

Your heating appliance, flue pipes and chimney can deteriorate over time. Look for corrosion or rust stains on the outer shell of a metal chimney and check for bulges or corrosion in its liner.



7 Watch for smoke coming into the room.

This could indicate a blockage in the chimney or a faulty damper control mechanism. Check it out!



8 Protect floors and walls from heat and sparks.

Keep combustibles safely away from your appliance. Always use a properly fitting screen for your fireplace.



Loose bricks, crumbling mortar, broken liners, dark stains or white powder indicate problems with masonry chimneys. These should be fixed immediately by a qualified mason.

For more information:

Contact your local fire department or a WETT Certified Chimney Sweep.

This pamphlet was produced with the support of the following:

G.S.W. Heating Products
James A. Ryder Manufacturing Inc.
Oliver-MacLeod
Security Chimney Ltd.
Selkirk Metalbestos
Clay Flue Lining Institute of Canada
Clay Brick Association of Canada
Ontario Association of Fire Chiefs
Ontario Municipal Fire Prevention Officers Association
Association of Registered Wood Energy Technicians of Ontario
Ontario Chimney Sweeps Association
The Office of the Fire Marshal of Ontario

